

KIT-30s

(art.271)

ENGLISH

ATTENTION

Plug in the connectors of the link cables to the displays **ONLY** when the power plug is disconnected.

FUSES

If with the power plug connected the red led on the console does not light up:

Verify the state of the fuse placed inside the console. To open the console:

- a) disconnect the power plug;
- b) unscrew the 4 black screws placed on the bottom;
- c) unscrew the 2 black screws placed on the up side;
- d) detach the frontal from the bottom.

The internal fuse is placed on the electronic board. If necessary, replace it with an equivalent one: 5 x20mm T2.5A fuse.

ITALIANO

ATTENZIONE

Inserire i connettori dei cavi di collegamento ai display **SOLO** quando la spina di alimentazione è disinserita.

FUSIBILI

Se con la spina di alimentazione inserita la spia rossa sulla console non si accende:

Verificare lo stato del fusibile posto internamente alla console. Per aprire la console:

- a) staccare l'alimentazione;
- b) svitare le 4 viti nere poste sul fondo;
- c) svitare le 2 viti nere poste sulla parte superiore;
- d) distaccare il frontale dal fondo.

Il fusibile interno è posto sulla scheda. Se necessario, sostituirlo con uno equivalente: fusibile 5x20mm T2.5A.